

HIGH PRESSURE TOOLS TOOLING

CONING TOOLS

- For preparing a "cone" on the 20 and 60 series tubing ends.

Tube O.D x I.D (in.)	Ordering number
1/4 x 0.109	HCT-M4
3/8 x 0.203	HCT-M6
9/16 x 0.312	HCT-M9
1/4 x 0.083	HCT-H4
3/8 x 0.125	HCT-H6
9/16 x 0.188	HCT-H9



THREADING TOOLS

- For preparing a left hand thread on the 20 and 60 series tubing ends.

Tube O.D x I.D (in.)	Ordering number	Thread size (Left Hand)
1/4	HTT-4	1/4-28 UNF
3/8	HTT-6	3/8-24 UNF
9/16	HTT-9	9/16-18 UNF



RESEATING TOOLS

- For repairing the damaged tube connector seats in 20 and 60 series tube fittings and valves.

Connection size (in.)	Connection type	Ordering number
1/4	2FH4	HRT-M4
3/8	2FH6	HRT-M6
9/16	2FH9	HRT-M9
3/4	2FH12	HRT-M12
1	2FH16	HRT-M16
1/4	6FH4	HRT-H4
3/8	6FH6	HRT-H6
9/16	6FH9	HRT-H9



MANUAL PRESETTING TOOLS

Tube O.D (in.)	Ordering number
1/8	PST-2
1/4	PST-4
3/8	PST-6
1/2	PST-8



HIGH PRESSURE HYDRAULIC PRESETTING TOOLS

Tube O.D (in.)	Ordering number
1/2, 9/16, 3/4	HPT-HF
Choose your needs from Die Heads e.g. HPT-H+HPT-H-FH8	HPT-H+U



DIE HEADS

Tube O.D (in.)	Ordering number
1/2	HPT-H-FH8
9/16	HPT-H-FH9
3/4	HPT-H-FH12

